



These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.

2.1 EXH-HW-KIT

Hardware & Gasket Kit for
1986-1991 Vanagon Exhaust System

This kit is designed to provide you with the necessary hardware and gaskets required to install the seven major exhaust components: the 1&3 Header, the 2&4 Header, the Collector Elbow, the Collector-to-Cat J-Pipe, the Catalytic Converter, the Muffler, and the Tail Pipe. Due to the fact that exhaust components can vary slightly between manufacturers, we have made our best attempt to provide you with the most accurate kit possible. Depending on your combination of parts, you may end up with some unused pieces of hardware and/or gaskets.

Installation Note: *It is recommended to leave all fasteners loose until everything is installed and clocked correctly. The final torque should be applied once everything is fitted properly.*

Note: *The new GoWesty SS exhaust does NOT reuse the stock hangers for the 1&3 and 2&4 headers.*

Number Key:

- 1) 2 Hole Gasket (qty.6)
- 2) 3 Hole Gasket w/Stainless (qty.2)
- 3) Tail Pipe Gasket (qty.1, not used with sport muffler)
- 4) Sealing Donut (qty.2)
- 5) 20mm Bolt [30mm for SS muffler] (qty.3, not used with sport muffler)
- 6) 30mm Bolt (qty.7)
- 7) 50mm Bolt (qty.6)
- 8) 35mm Bolt (qty.10)

Installation Note:

The Copper Locking Nuts (qty.16) are to be used on all through-bolt connections. The Zinc Plated Nuts (qty. 4) are used on the studs at the head exhaust port locations. The J-pipe to Cat connection may use 50mm or 35mm bolts depending on type of gasket used.

