



KT-VANO

3-Point Retracting Seat Belt
(Front LH/RH), 1980 - 1991

Tools Needed:

Philips Screwdriver
Flat Head Screwdriver
17mm Wrench or Drive

Tired of those seat belts that won't retract anymore? Is the webbing all worn and frayed? Replace those tired old 3-point belts with our high quality replacement kit. It fits all years of Vanagon, driver or passenger side, and includes a brand-new receiver.

Before installing the seatbelt in your vehicle, please watch the installation videos linked on the product web-page.

If you have a full camper, the driver side may pose more of a challenge. There is also a video on the product web-page to help explain the nuances of your installation.

Passenger Side Installation

1.



Begin by removing the phillips head screw to release and remove the plastic shroud over the reel. Your van may not have this cover.

2.



Unsnap the reel cover, and remove the 17mm bolt holding the reel. You may need to unreel the webbing to fit a wrench or socket in place

3-Point Retracting Seat Belt (Front LH/RH), 1980 -1991

3.



Remove the D-Ring. You will need to remove the cover to access the bolt.

4.



Remove the bolt cap, and bolt to remove the belt end from the seat pedestal

5.



Remove the hardware and save for the new belt. The plastic ring may need to be cut or pried off to remove the hardware.

6.



Remove some slack from the new reel. It will not unravel unless it is in an upright, vertical position.

7.



Bolt the new reel in, taking care to ensure it is vertically straight. Torque the reel bolt to 35 lb-ft

8.



Unsnap the D-Ring cover and bolt the D-Ring in place. Be sure the mounting hole is squared on the shoulder of the bolt, so it pivots freely. Torque to 35 lb-ft



GOWESTY

3-Point Retracting Seat Belt (Front LH/RH), 1980 -1991

9.



Install the bolt down end of the webbing with the saved hardware. Torque to 35 lb-ft

10.



Reinstall the reel cover.

If you have a full camper, see the next page, otherwise repeat for the drivers side, and you are done!



3-Point Retracting Seat Belt (Front LH/RH), 1980 -1991

Full Camper Driver Side Installation

It may be helpful to remove the drivers seat, but it is not necessary.

1.



Pull the webbing out of the reel to easily access the bolt. Remove the bolt, and unsnap the cover to provide enough room to wiggle the reel out.

2.



Lift the lid and unscrew the guide bar .

3.



Rotate the guide bar up and pull it out.

4.



Remove the bolt down end.

5.



Remove the D-ring end.

6.



Install your new belt in reverse of removal. Torque all bolts to 35 lb-ft.

You are done!



GOWESTY