



These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.

AISLE-TRIM-KIT Vanagon Aisle Trim Kit

Installation Notes:

- Start by removing the original metal strip located in the aisle.
- Place your new aisle trim piece in place. Be sure that it is centered correctly in the aisle.
- Use the included self-drilling screws to secure the trim piece in place. The screws will drill **new** mounting holes.



GoWesty Camper Products • 1119 Los Olivos Ave, Los Osos, CA 93402 • 888-469-3789 • www.gowesty.com



These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.

AISLE-TRIM-KIT Vanagon Aisle Trim Kit

Installation Notes:

- Start by removing the original metal strip located in the aisle.
- Place your new aisle trim piece in place. Be sure that it is centered correctly in the aisle.
- Use the included self-drilling screws to secure the trim piece in place. The screws will drill **new** mounting holes.



GoWesty Camper Products • 1119 Los Olivos Ave, Los Osos, CA 93402 • 888-469-3789 • www.gowesty.com