





- Remove armrest using a 6mm hex key.
- Remove any broken pieces from the mounting area of the armrest; it should look like one of the armrests in the photo on the left.
- Place the fix plate over the broken area and reinstall using your original bolt.
- A dab of glue or epoxy can help hold the plate in place during reinstallation.
- There you go! Your arms are now ready to be rested again!

GoWesty Camper Products • 1119 Los Olivos Ave, Los Osos, CA 93402 888-469-3789 • www.gowesty.com

These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.







- Remove armrest using a 6mm hex key.
- Remove any broken pieces from the mounting area of the armrest; it should look like one of the armrests in the photo on the left.
- Place the fix plate over the broken area and reinstall using your original bolt.
- A dab of glue or epoxy can help hold the plate in place during reinstallation.
- There you go! Your arms are now ready to be rested again!