




These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.

## FRONT-SUSP-HW-C-2WD

Front Suspension Hardware Kit for  
2WD Vanagon with Cast Control Arms


Did you notice a bunch of rusty and corroded bolts the last time you crawled under your Vanagon? Give those critical suspension components a better-than-OEM shine with this class 10.9 steel, zinc-coated hardware, and take a deep breath with the knowledge that your suspension hardware is fresh, just like the air you'll breathe when you arrive safely at your destination.

<b>Hardware List</b> 	<b>Part # in Diagram</b>
(2) Lower Control Arm Bolt: M12x1.5x110 Hex Partial	18
(2) Lower Control Arm Nut: M12 Hex Nut	19
(2) Lower Control Arm Washer: M12 Mech Lock	18A
(2) Radius Rod Nut: M18x1.5 Hex Nut	6
(2) Radius Rod Lock Nut: M18x1.5 Nylock Nut	6A
(2) Front Lower Shock Bolt: M14x1.5x110 Hex Partial	11D
(2) Front Lower Shock Nut: M14x1.5 Hex	11B

### **Bolt Size Chart**

Check here to make sure you're using the correct size bolts. Length is measured from the underside of the bolt head. Bolt size is measured from the outside edges of the threads.

Lower Control Arm Bolt: M12x1.5x110 Hex Partial



Front Lower Shock Bolt: M14x1.5x110 Hex Partial





These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.

## FRONT-SUSP-HW-C-2WD

Front Suspension Hardware Kit for  
2WD Vanagon with Cast Control Arms

