






These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.

GVW-251-411-085

Syncro Sway Bar Riser
1986-1991 Vanagon Syncro

Volkswagen included a sway bar adaptor block for Syncro (4WD) Vanagons. These blocks allow the Syncro and 2WD to share the same sway bar while clearing the steering rack. While many expensive aftermarket solutions exist, GoWesty is proud to provide a cost-effective, simple, and to-the-point solution to keep your Syncro on the road!

Tools Required 	Hardware List 	Parts List 
13mm Wrench or Socket Press Nut Tool <i>(Optional)</i>	(12) M8 Washers (4) M8 Thick Washers (1) Packet Anti-seize (8) M8 Nylock Nuts (8) M8 x 25mm Bolts	(2) SS Sway Bar Spacer

Installation Note: *Liberally apply anti-seize to all stainless-steel fastener junctions. Stainless-steel fasteners can bind if installed without anti-seize – when this happens, there is usually no recourse except to cut them off and start over with fresh fasteners. Using anti-seize compound prevents this from happening, so don't skimp on the anti-seize when installing!*

Installation Instructions

- 1) Install the spacer underneath the mounting lip using the 8mm washers, nuts, and bolts.



- 2) Install the sway bar with the rubber bushing and strap. Send the 8mm bolts through the strap, making sure to include the thick washers. Repeat for the other side.



That's it! You're ready to hit the trails!