



GVW-255-405(B)
Curtain Hold Back Stretch Cord

- 1) Determine which eye-screw (large or small) will work with the mounting screw on your vehicle.
- 2) Screw **one** eye-screw into **one** end of Stretch Cord until threads are completely in the cord.
AT THIS POINT DO NOT SCREW EYE-SCREWS INTO BOTH ENDS!
- 3) Attach end to vehicle using mounting screw and stretch cord to second mounting screw (to desired tension).
- 4) If necessary, cut Stretch Cord and screw second eye-screw completely into Stretch Cord.
- 5) Attach to vehicle using mounting screw.



GVW-255-405(B)
Curtain Hold Back Stretch Cord

- 1) Determine which eye-screw (large or small) will work with the mounting screw on your vehicle.
- 2) Screw **one** eye-screw into **one** end of Stretch Cord until threads are completely in the cord.
AT THIS POINT DO NOT SCREW EYE-SCREWS INTO BOTH ENDS!
- 3) Attach end to vehicle using mounting screw and stretch cord to second mounting screw (to desired tension).
- 4) If necessary, cut Stretch Cord and screw second eye-screw completely into Stretch Cord.
- 5) Attach to vehicle using mounting screw.



GVW-255-405(B)
Curtain Hold Back Stretch Cord

- 1) Determine which eye-screw (large or small) will work with the mounting screw on your vehicle.
- 2) Screw **one** eye-screw into **one** end of Stretch Cord until threads are completely in the cord.
AT THIS POINT DO NOT SCREW EYE-SCREWS INTO BOTH ENDS!
- 3) Attach end to vehicle using mounting screw and stretch cord to second mounting screw (to desired tension).
- 4) If necessary, cut Stretch Cord and screw second eye-screw completely into Stretch Cord.
- 5) Attach to vehicle using mounting screw.



GVW-255-405(B)
Curtain Hold Back Stretch Cord

- 1) Determine which eye-screw (large or small) will work with the mounting screw on your vehicle.
- 2) Screw **one** eye-screw into **one** end of Stretch Cord until threads are completely in the cord.
AT THIS POINT DO NOT SCREW EYE-SCREWS INTO BOTH ENDS!
- 3) Attach end to vehicle using mounting screw and stretch cord to second mounting screw (to desired tension).
- 4) If necessary, cut Stretch Cord and screw second eye-screw completely into Stretch Cord.
- 5) Attach to vehicle using mounting screw.