



These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.

GVW-ENGEL-TETHER

Tie Down Strap for Engel Fridge [All Vanagon and Eurovan]

Installing Mounting Points

Vanagon: Sandwich the included tie down loops in between the washers on the inside of the seatbelt buckle and seat pedestal. Insert the bolt through the large hole in the loop and torque to approximately 45 ft-lbs.

Eurovan 7 Passenger: Remove the rear pedestal nuts and add the included washer onto the stud before adding the tie down loop. Reinstall the nut and torque to approximately 45 ft-lbs.

Eurovan Multivan/Weekender: Install the included loops on the M6 bolts at the top-rear of the pedestal as shown to the right.

Eurovan Winnebago Camper: Remove the passenger side, rear pedestal bolts and install the L-brackets with the included longer bolts, using the spacers under the brackets. Torque to approximately 45 ft-lbs.



Installing Fridge in Vehicle

- 1) Clip the included carabiner through the small loop of webbing on the strap. Pinching the sides of the webbing in where it seats in the small end of the carabiner helps it to sit cleanly.
- 2) Loop the webbing through the fridge handle and insert it into the cam buckle.
- 3) Place the fridge in the van behind the passenger seat and attach the carabiners to the eyebolts or brackets as appropriate. Tighten up the straps and tuck any excess webbing out of the way. *Note: The webbing is made with some extra length, but it can be cut to any convenient length and sealed with heat to prevent unravelling.*

GoWesty Camper Products • 1119 Los Olivos Ave, Los Osos, CA 93402 • 888-469-3789 • www.gowesty.com

Page 1 of 1



These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.

GVW-ENGEL-TETHER

Tie Down Strap for Engel Fridge [All Vanagon and Eurovan]

Installing Mounting Points

Vanagon: Sandwich the included tie down loops in between the washers on the inside of the seatbelt strap and seat pedestal. Insert the bolt through the large hole in the loop and torque to approximately 45 ft-lbs.

Eurovan 7 Passenger: Remove the rear pedestal nuts and add the included washer onto the stud before adding the tie down loop. Reinstall the nut and torque to approximately 45 ft-lbs.

Eurovan Multivan/Weekender: Install the included loops on the M6 bolts at the top-rear of the pedestal as shown to the right.

Eurovan Winnebago Camper: Remove the passenger side, rear pedestal bolts and install the L-brackets with the included longer bolts, using the spacers under the brackets. Torque to approximately 45 ft-lbs.



Installing Fridge in Vehicle

- 1) Clip the included carabiner through the small loop of webbing on the strap. Pinching the sides of the webbing in where it seats in the small end of the carabiner helps it to sit cleanly.
- 2) Loop the webbing through the fridge handle and insert it into the cam buckle.
- 3) Place the fridge in the van behind the passenger seat and attach the carabiners to the eyebolts or brackets as appropriate. Tighten up the straps and tuck any excess webbing out of the way. *Note: The webbing is made with some extra length, but it can be cut to any convenient length and sealed with heat to prevent unravelling.*

GoWesty Camper Products • 1119 Los Olivos Ave, Los Osos, CA 93402 • 888-469-3789 • www.gowesty.com

Page 1 of 1