





These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.

GW-B-SHOCK-HW
Bus Shock Hardware Kit
1968-1979

This hardware kit is compatible with your OE shocks and our new FoxShocks for Bus. Replace your original hardware for added peace of mind and easy installation and removal.

Tools Required 	Hardware List 	
19mm Wrench or Socket	M12x90mm Bolt (2)	M12 Flat Washer (12)
17mm Wrench or Socket	M12x100mm Bolt (2)	M12 Lock Washer (2)
	M12x110mm Bolt (2)	M12 Nylock Nut (6)
	M10 Wave Washer (2)	M10 Nylock Nut (2)

Installation

Front Top: M12x90mm Bolt, Flat Washer, Shock, Through Body, Flat Washer, Nylock Nut

Front Bottom: Suspension Stud, Shock, Flat Washer, Nylock Nut

Rear Top: M12 x 110mm Bolt, Lock Washer, Flat Washer, Shock, Body

Rear Bottom: M12 x 90mm Bolt, Flat Washer, Shock, Body, Flat Washer, Nylock Nut

Note: Early bay window busses have a different lower, front shock mounting stud that is shorter and has 10mm instead of 12mm threads. This hardware kit includes two 10mm wavy washers and nuts for this case. Depending on the length of the stud remove one or both of the 12mm flat washers included in the hardware kit as needed to obtain full nut thread engagement.



GoWesty Camper Products • 1119 Los Olivos Ave, Los Osos, CA 93402 • 888-469-3789 • www.gowesty.com



These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.

GW-B-SHOCK-HW
Bus Shock Hardware Kit
1968-1979

This hardware kit is compatible with your OE shocks and our new FoxShocks for Bus. Replace your original hardware for added peace of mind and easy installation and removal.

Tools Required 	Hardware List 	
19mm Wrench or Socket	M12x90mm Bolt (2)	M12 Flat Washer (12)
17mm Wrench or Socket	M12x100mm Bolt (2)	M12 Lock Washer (2)
	M12x110mm Bolt (2)	M12 Nylock Nut (6)
	M10 Wave Washer (2)	M10 Nylock Nut (2)

Installation

Front Top: M12x90mm Bolt, Flat Washer, Shock, Through Body, Flat Washer, Nylock Nut

Front Bottom: Suspension Stud, Shock, Flat Washer, Nylock Nut

Rear Top: M12 x 110mm Bolt, Lock Washer, Flat Washer, Shock, Body

Rear Bottom: M12 x 90mm Bolt, Flat Washer, Shock, Body, Flat Washer, Nylock Nut

Note: Early bay window busses have a different lower, front shock mounting stud that is shorter and has 10mm instead of 12mm threads. This hardware kit includes two 10mm wavy washers and nuts for this case. Depending on the length of the stud remove one or both of the 12mm flat washers included in the hardware kit as needed to obtain full nut thread engagement.

GoWesty Camper Products • 1119 Los Olivos Ave, Los Osos, CA 93402 • 888-469-3789 • www.gowesty.com