



These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.

HP-ABS

ABS PLASTIC REAR HATCH PANEL FOR VANAGON

The HP-ABS for Vanagon is CNC-machined to fit the interior rear hatch panel. Made from nearly-indestructible, 3mm thick, ABS plastic, this panel can be run as-is (they look awesome), painted with a high-quality plastic paint, or upholstered.

Fitment Note: Some rare late-model vans have an interior hatch release. This cutout is not included on our ABS panels. If you have this hatch release, you will need to trace the hole from your existing panel onto the ABS panel and then cut it out.

Installation:

1. Place the panel over the door, aligning the mounting hole cutouts.
2. Screw in each Panel Fastener snugly using a Phillips-head screwdriver. Slight inward pressure can be used, but forcing the clips all the way in will make the clip hard to remove.

Be careful not to over-tighten and do not push the clips in without turning them.

GoWesty Camper Products • 1119 Los Olivos Ave, Los Osos, CA 93402 • 888-469-3789 • www.gowesty.com



These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.

HP-ABS

ABS PLASTIC REAR HATCH PANEL FOR VANAGON

The HP-ABS for Vanagon is CNC-machined to fit the interior rear hatch panel. Made from nearly-indestructible, 3mm thick, ABS plastic, this panel can be run as-is (they look awesome), painted with a high-quality plastic paint, or upholstered.

Fitment Note: Some rare late-model vans have an interior hatch release. This cutout is not included on our ABS panels. If you have this hatch release, you will need to trace the hole from your existing panel onto the ABS panel and then cut it out.

Installation:

1. Place the panel over the door, aligning the mounting hole cutouts.
2. Screw in each Panel Fastener snugly using a Phillips-head screwdriver. Slight inward pressure can be used, but forcing the clips all the way in will make the clip hard to remove.

Be careful not to over-tighten and do not push the clips in without turning them.

GoWesty Camper Products • 1119 Los Olivos Ave, Los Osos, CA 93402 • 888-469-3789 • www.gowesty.com