



These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.

KT122-EVC

3-point seat belt kit for
'95 Eurovan Full Camper

This kit provides everything needed to install 3-point belts for the '95 Eurovan full camper, which came from factory with lap-belts.

The installation of this kit does require drilling and slight modification to your van. Please read through these instructions carefully and then decide if installing them is within your capabilities. If not, take your vehicle to an automotive technician.

Tools Needed

- Drill
- 7/16" drill bit
- Torque wrench

There is a hole under the headliner material in of the rear most bolster that will need to

be exposed. Use this hole as center, and drill a 7/16" hole on the front face of the bolster for the eyebolt. Use the larger rear hole to insert the backing plate, spring washer and nut. Torque nut to 40-45 ft. lbs. Cap the exposed hole with the provided grommet.

Replace the existing receivers on the backside center of the seat with the new reels. Orient the reels with the webbing exiting vertically, and torque the bolts to 40-45 ft. lbs. Replace the out-board stock belts with the new receivers, torque bolts to 40-45 ft. lbs.

Clip the ends of the belts into the eyebolt.



And that's it!

