



## KT122-LHC

SPECIAL INSTRUCTIONS AND PARTS  
FOR CABINET SIDE INSTALLATION

### Cabinet side shoulder belt installation kit

1. Bus/Vanagon full campers require you to cut two slots into the cabinetry through which the seat belt webbing will pass. The first slot will be immediately in front of the inertia reel (through the back wall of the closet). The second slot will be just behind the left shoulder of the L.H. rear passenger. Please refer to the photos provided to install the oval rosettes in this kit. NOTE: Bus installation is similar, although not identical, to Vanagon. See reverse for Bus installation photos.



### Vanagon Installation Photos

# Bus Installation Photos

