

- 1) Remove rear heater.
- 2) Pull heater hoses through to outside of vehicle.
- 3) Replace factory T-fittings with straight fittings (re-use or replace clamps as necessary).
- 4) Remove grommets and use body plugs to seal the holes for the hoses. *Note: The body* plugs are a very snug fit. Using a flat screwdriver to massage it into place is helpful.
- 5) Tuck the wiring harness out of the way to prevent any accidental shorts.
- 6) You can replace the heater hold-down screws or just dab some sealant over the holes to seal them up.
- 7) Top off your coolant.
- 8) Smile. You're done.

Enjoy that extra space you've just gained!

GoWesty Camper Products • 1119 Los Olivos Ave, Los Osos, CA 93402 • 888-469-3789 • www.gowesty.com



These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited. REAR-HEAT-DELETE Vanagon Rear Heater Removal Kit

- 1) Remove rear heater.
- 2) Pull heater hoses through to outside of vehicle.
- 3) Replace factory T-fittings with straight fittings (re-use or replace clamps as necessary).
- 4) Remove grommets and use body plugs to seal the holes for the hoses. *Note: The body* plugs are a very snug fit. Using a flat screwdriver to massage it into place is helpful.
- 5) Tuck the wiring harness out of the way to prevent any accidental shorts.
- 6) You can replace the heater hold-down screws or just dab some sealant over the holes to seal them up.
- 7) Top off your coolant.
- 8) Smile. You're done.

Enjoy that extra space you've just gained!