



These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.

VANO-UNI-ROTOPAX Rotopax Mount For Universal Carrier

1. Use the 2.75" long stainless steel bolts and washers to sandwich the 2" square tubing of the universal carrier between the backing plate and the Rotopax carrier base. Use the supplied Loctite on the bolt threads to prevent them from loosening.
2. It is recommended to add the provided self-drilling screws in the locations shown in the picture to the right.



GoWesty Camper Products • 1119 Los Olivos Ave, Los Osos, CA 93402 • 888-469-3789 • www.gowesty.com



These instructions and the images herein are proprietary. Any unauthorized reproduction is prohibited.

VANO-UNI-ROTOPAX Rotopax Mount For Universal Carrier

1. Use the 2.75" long stainless steel bolts and washers to sandwich the 2" square tubing of the universal carrier between the backing plate and the Rotopax carrier base. Use the supplied Loctite on the bolt threads to prevent them from loosening.
2. It is recommended to add the provided self-drilling screws in the locations shown in the picture to the right.



GoWesty Camper Products • 1119 Los Olivos Ave, Los Osos, CA 93402 • 888-469-3789 • www.gowesty.com