



BROADWAY GANGING KIT

#G-BRD

To be used to hang any Broadway Cabinets side by side only. Each Kit will hang two cabinets together side by side. If you are hanging more than two cabinets, additional kits are needed to gang extra cabinets together.

INSTALLATION INSTRUCTIONS:

- 1) The 2 aluminum blocks go between the 2 cabinets outer sides (1 top/ 1 bottom).
- 2) Secure with 4 screws provided on each side, and align the screw holes.
- 3) 2 screws go into the top two parallel holes on the inside of the cabinet. Place the screws into the hole and thread into the aluminum block on the outside until secure.
- 4) 2 screws go into the bottom parallel holes..... repeating step #3
- 5) Repeat steps #3 and #4 on the opposite side to gang the two cabinets together,
- 6) Make sure all 8 screws are tight and secure.

PARTS LIST:

- 2 -aluminum ganging blocks
 - 8 -threaded screws
-