

RP8 and KP8 pairing

Step 1: Turn relay pack on by pressing power button (#1 in drawing) all buttons should light up.

Step 2: Hold the 2 outside buttons on relay pack down (#2 and #3 in drawing) until all buttons are flashing.

Step 3: Turn keypad on by pressing power button (#4 in drawing) all buttons should light up.

Step 4: Hold the 2 outside buttons on keypad down (#5 and #6 in drawing) until all buttons are flashing. Then all buttons will flash 3 quick times and keypad will turn off.

Step 5: Hold the 2 outside buttons on relay pack down (#2 and #3 in drawing) until all buttons stop flashing. Keypad and relay pack are now paired

