Efflorescence by Amanda Greene / #82010 / 45 Designs





by Amanda Greene / #82010 / 45 Designs

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.



82010-01 Flowers Group Jumbo

8.46 X 11.48 in. 214.88 X 291.59 mm 50,975 St. **₩**♥ L



82010-02 Flowers Group 1

4.81 X 6.92 in. 122.17 X 175.77 mm 24,679 St. **₩** ∴ L



82010-03 Flowers Group 2

4.69 X 5.43 in. 119.13 X 137.92 mm 17,929 St. **₩** L



82010-04 Flowers Group 3

5.01 X 5.92 in. 127.25 X 150.37 mm 19,320 St. **#** L



82010-05 Flower & Leaves

6.84 X 4.15 in. 173.74 X 105.41 mm 17,509 St. ₩≎ L



82010-06 Blooming Flower 1

4.19 X 6.84 in. 106.43 X 173.74 mm 25,288 St. **#** C L



8010-07 Blooming Flower 2 3.54 X 6.34 in.

3.54 X 6.54 in. 89.92 X 161.04 mm 16,065 St. ₩≎ L




82010-08 Blooming Flower 3

3.24 X 5.83 in. 82.30 X 148.08 mm 14,830 St. **#** L



82010-09 Blooming Flower 4

2.35 X 4.76 in. 59.69 X 120.90 mm 8,482 St. **₩**



82010-10 Blooming Flower 5

2.23 X 4.09 in. 56.64 X 103.89 mm 6,087 St. ₩≎



82010-11 Flower Pot

3.37 X 3.03 in. 85.60 X 76.96 mm 11,761 St. ₩♀



82010-12 Flower 1

4.66 X 4.74 in. 118.36 X 120.40 mm 18,201 St. **₩**❖

- # Design contains a loose fill.
- Some solid areas shown are not stitched.

- L Design is larger than 5" (127 mm) in either direction.
- S Design is smaller than 1.5" (38.1 mm) in either direction.



by Amanda Greene / #82010 / 45 Designs

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.







82010-13 Flower 2 2.96 X 2.99 in. 75.18 X 75.95 mm 8,817 St. **₩**○

82010-14 Flower Group Border 6.66 X 2.89 in. 169.16 X 73.41 mm 12,827 St. ₩ L

82010-15 Hummingbird 1 4.87 X 4.88 in. 123.70 X 123.95 mm 11,866 St. **₩**♥

82010-16 Hummingbird 2 5.72 X 3.87 in. 145.29 X 98.30 mm 13,267 St. ₩≎ L



82010-17 Paisley 3.60 X 5.00 in. 91.44 X 127.00 mm 14,260 St. **₩**○



82010-18 Fleur-de-lis 4.82 X 4.99 in. 122.43 X 126.75 mm 15,781 St. **₩**○



82010-19 Heart 4.27 X 4.28 in. 108.46 X 108.71 mm 15,452 St. **₩**♥



82010-20 Bloom 9.60 X 3.21 in. 243.84 X 81.53 mm 24,698 St. **₩**♀ L



82010-21 Leaf Branch 1 3.40 X 4.89 in. 86.36 X 124.21 mm 10,855 St. ₩≎



82010-22 Leaf Branch 2 2.94 X 4.02 in. 74.68 X 102.11 mm 8,271 St. ₩○



82010-23 Small Paisley 2.39 X 2.63 in. 60.71 X 66.80 mm 4,513 St. **₩**○



82010-24 Vine 1 4.43 X 4.75 in. 112.52 X 120.65 mm 13,224 St. ₩≎

- # Design contains a loose fill.
- Some solid areas shown are not stitched.

- L Design is larger than 5" (127 mm) in either direction.
- S Design is smaller than 1.5" (38.1 mm) in either direction.



by Amanda Greene / #82010 / 45 Designs


Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.



82010-25 Vine 2 3.57 X 5.71 in. 90.68 X 145.03 mm 10,763 St. ₩≎ L



82010-26 Vine 3 2.32 X 3.61 in. 58.93 X 91.69 mm 6,181 St. ₩≎



82010-27 Vine 4 1.96 X 2.63 in. 49.78 X 66.80 mm 3,284 St. ₩≎




82010-28 Flower Square 1 4.87 X 4.87 in. 123.70 X 123.70 mm 22,583 St. ₩○




82010-29 Flower Square 2 4.93 X 4.93 in. 125.22 X 125.22 mm 21,842 St. ₩♥




82010-30 Flower Square 3 4.90 X 4.90 in. 124.46 X 124.46 mm 27,993 St. ₩○



82010-31 Flower Square 44.92 X 4.92 in.
124.97 X 124.97 mm
22,131 St. **₩**○



82010-32 Flower Lace Square 4.85 X 4.85 in. 123.19 X 123.19 mm 23,915 St. ₩♥



82010-33 Linework Flower Square

4.99 X 4.99 in. 126.75 X 126.75 mm 10,390 St. **₩**○



82010-34 Flower Lace Center

5.85 X 2.88 in. 148.59 X 73.15 mm 9,936 St. **₩**♀ L



82010-35 Flower Lace 1 4.07 X 5.40 in. 103.38 X 137.16 mm 11,931 St. ₩≎ L



3.14 X 4.42 in. 79.76 X 112.27 mm 8,239 St. ₩≎

- # Design contains a loose fill.
- Some solid areas shown are not stitched.

- L Design is larger than 5" (127 mm) in either direction.
- S Design is smaller than 1.5" (38.1 mm) in either direction.



by Amanda Greene / #82010 / 45 Designs

Note: Some designs in this collection may have been created using unique special stitches and/or techniques. To preserve design integrity when rescaling or rotating designs in your software, always rescale or rotate designs using the handles directly on-screen.




82010-37 Flower Lace 3 3.45 X 4.57 in.

87.63 X 116.08 mm 11,094 St. **#**



82010-38 Flower Lace 4

2.90 X 3.39 in. 73.66 X 86.11 mm 5,891 St. ₩≎




82010-39 Flower Lace 5

3.90 X 3.90 in. 99.06 X 99.06 mm 12,549 St. ₩♡




82010-40 Flower Lace Mini

2.38 X 2.41 in. 60.45 X 61.21 mm 5,006 St. **₩**♥




82010-41 Linework Flower 1

4.91 X 4.91 in. 124.71 X 124.71 mm 8,263 St. **₩**



82010-42 Linework Flower 2

4.78 X 6.03 in. 121.41 X 153.16 mm 8,256 St. **₩**♥ L



82010-43 Linework Flower 3

4.20 X 5.31 in. 106.68 X 134.87 mm 7,388 St. **₩**♀ L



82010-44 Linework Leaf Border

6.46 X 1.66 in. 164.08 X 42.16 mm 3,627 St. **₩** L



82010-45 Linework Leaf Corner

3.48 X 3.47 in. 88.39 X 88.14 mm 3,261 St. ₩≎

- # Design contains a loose fill.
- Some solid areas shown are not stitched.

- L Design is larger than 5" (127 mm) in either direction.
- S Design is smaller than 1.5" (38.1 mm) in either direction.



by Amanda Greene / #82010 / 45 Designs

Listings below indicate color sample, stitching order and suggested thread color number. Most numbers indicate Isacord thread. However, colors beginning with 20501 refer to YLI Fine Metallics, 7 refer to Yenmet Metallic, 8 refer to YLI Variations Variegated Thread and 9 refer to Isacord Multicolor Variegated.

820	10-01 Flowers Group Jumbo		82010-08 Blooming Flower 3		82010-17 Paisley	
	1. Gold Detail	0721	1. Gold Detail	0721	1. Green Detail	0352
	2. Tan Detail	0672	2. Green Detail	0352	2. Blue Detail	4620
	3. Green Detail	0352	3. Tan Detail	0672	3. Green Detail	0352
	4. Blue Detail	4620	4. Blue Detail	4620	4. Tan Detail	
	5. Green Detail	0352	5. Green Detail	0352	5. Gold Detail	0721
	6. Gray Detail		6. Gray Detail		6. Gray Detail	0152
	7. Tan Detail	0672	7. Tan Detail	0672		
	8. Gray Detail	0152	8. Gray Detail	0152	82010-18 Fleur-de-lis	
					1. Tan Detail	0672
820	10-02 Flowers Group 1		82010-09 Blooming Flower 4		2. Gold Detail	0721
	1. Gold Detail		1. Gold Detail		3. Green Detail	
	2. Green Detail	0352	2. Green Detail	0352	4. Blue Detail	4620
	3. Tan Detail		3. Blue Detail		5. Gray Detail	0152
	4. Blue Detail	4620	4. Tan Detail	0672		
	5. Green Detail	0352	5. Gray Detail	0152	82010-19 Heart	
	6. Gray Detail	0152	6. Tan Detail		1. Tan Detail	0672
	7. Tan Detail	0672	7. Gray Detail	0152	2. Gold Detail	0721
	8. Gray Detail				3. Green Detail	0352
	9. Blue Detail	4620	82010-10 Blooming Flower 5		4. Blue Detail	4620
			1. Gold Detail	0721	5. Gray Detail	0152
820	10-03 Flowers Group 2		2. Blue Detail	4620	•	
	1. Gold Detail	0721	3. Tan Detail	0672	82010-20 Bloom	
	2. Tan Detail	0672	4. Green Detail	0352	1. Gold Detail	0721
	3. Blue Detail		5. Gray Detail	0152	Slue Detail	
	4. Green Detail	0352	6. Tan Detail	0672	3. Gray Detail	
	5. Gray Detail	0152	7. Gray Detail	0152	4. Green Detail	
	6. Tan Detail	0672				
	7. Gray Detail	0152	82010-11 Flower Pot		82010-21 Leaf Branch 1	
	8. Green Detail	0352	1. Green Detail	0352	1. Gold Detail	0721
			2. Gold Detail		Slue Detail	
820	10-04 Flowers Group 3		3. Gray Detail		3. Green Detail	
	1. Gold Detail	0721	•		4. Gray Detail	
	2. Green Detail		82010-12 Flower 1		5. Tan Detail	
	3. Blue Detail		1. Gold Detail	0721	6. Gray Detail	
	4. Green Detail	0352	2. Tan Detail		0. 0.u _j 20u	
	5. Gray Detail		3. Blue Detail		82010-22 Leaf Branch 2	
	6. Tan Detail	0672	4. Green Detail		1. Gold Detail	0721
	7. Gray Detail		5. Tan Detail		2. Blue Detail	
	8. Blue Detail		6. Gray Detail		3. Green Detail	
					4. Gray Detail	
820	10-05 Flower & Leaves		82010-13 Flower 2		5. Tan Detail	
	1. Gold Detail	0721	1. Gold Detail	0721	6. Gray Detail	
	2. Green Detail		Green Detail		— 0. Gray Dotair	0102
	3. Blue Detail		3. Blue Detail		82010-23 Small Paisley	
	4. Green Detail		4. Green Detail		1. Blue Detail	4620
	5. Tan Detail		5. Tan Detail		2. Gray Detail	
	6. Gray Detail		6. Gray Detail		2. Gray Detail	0152
	•		— 0. Gray Detail	0102	00040 04 777 4	
			92010 14 Flores Cross Pondon		82010-24 Vine 1	0704
820	10-06 Blooming Flower 1		82010-14 Flower Group Border 1. Gold Detail	0724	1. Gold Detail	
	1. Gold Detail	0721	2. Blue Detail		2. Blue Detail	
	2. Green Detail		3. Green Detail		3. Green Detail	
	3. Tan Detail		4. Tan Detail		4. Gray Detail	
	4. Blue Detail		5. Gray Detail		5. Tan Detail	0672
	5. Green Detail		6. Tan Detail			
	6. Gray Detail		0. Idii Deldii	0072	82010-25 Vine 2	
	7. Tan Detail		00040 45 33		1. Blue Detail	
	8. Gray Detail		82010-15 Hummingbird 1	0704	2. Green Detail	
_	o. Gray Dotali	0102	1. Gold Detail		3. Gold Detail	
920	10-07 Blooming Flower 2		2. Blue Detail		4. Gray Detail	
020		0704	3. Green Detail		5. Tan Detail	0672
	Gold Detail Green Detail		4. Tan Detail			
			5. Gray Detail	0152	82010-26 Vine 3	
	3. Gray Detail				1. Gold Detail	0721
	4. Tan Detail		82010-16 Hummingbird 2		2. Blue Detail	4620
	Blue Detail	4620	1. Gold Detail		3. Green Detail	0352
	6. Cray Datail	0450				
	6. Gray Detail	0152	2. Green Detail	0352	4. Gray Detail	0152
_	6. Gray Detail	0152	2. Green Detail 3. Green Detail		4. Gray Detail	
-	6. Gray Detail	0152	3. Green Detail	0352 4620	,	
	6. Gray Detail	0152	3. Green Detail	0352 4620	,	
	6. Gray Detail	0152	3. Green Detail	0352 4620 0672	,	



by Amanda Greene / #82010 / 45 Designs

Listings below indicate color sample, stitching order and suggested thread color number. Most numbers indicate Isacord thread. However, colors beginning with 20501 refer to YLI Fine Metallics, 7 refer to Yenmet Metallic, 8 refer to YLI Variations Variegated Thread and 9 refer to Isacord Multicolor Variegated.


82010-27 Vine 4	
1. Gold Detail	0721
2. Blue Detail	4620
3. Green Detail	0352
4. Gray Detail	0152
5. Tan Detail	0672
82010-28 Flower Square 1	
1. Gold Detail	0721
2. Tan Detail	
3. Blue Detail	4620
4. Green Detail	0352
5. Gray Detail	0152
6. Tan Detail	0672
82010-29 Flower Square 2	
1. Green Detail	
2. Gold Detail	
3. Tan Detail	
4. Blue Detail	
5. Gray Detail	0152
82010-30 Flower Square 3	
1. Green Detail	0352
2. Tan Detail	0672
3. Gold Detail	0721
4. Blue Detail	4620
5. Gray Detail	0152
82010-31 Flower Square 4	
1. Gold Detail	
2. 0.00200	
0. 5.00 5000	
T. OICCII DOIGII	
5. Tan Detail	
6. Gray Detail	0152

82010-32 Flower Lace Square 1. Single Color Design0152
82010-33 Linework Flower Square 0352 1. Green Detail 4620
82010-34 Flower Lace Center ■ 1. Gray Detail
82010-35 Flower Lace 1 ■ 1. Gray Detail
82010-36 Flower Lace 2 1. Gray Detail
82010-37 Flower Lace 3 ■ 1. Gray Detail 0152 2. Tan Detail 0672 ■ 3. Green Detail 0352 ■ 4. Blue Detail 4620
82010-38 Flower Lace 4 1. Gray Detail

82010-39 Flower Lace 5 1. Single Color Design	352
82010-40 Flower Lace Mini 1. Single Color Design	152
82010-41 Linework Flower 1 1. Green Detail	
82010-42 Linework Flower 2 1. Green Detail	
82010-43 Linework Flower 3 1. Green Detail	
82010-44 Linework Leaf Border 1. Green Detail	
82010-45 Linework Leaf Corner 1. Green Detail	



by Amanda Greene / #82010 / 45 Designs



NOTE: Paint colors listed refer to Fabrico Fabric Pens using the bullet tip. The number is the recommended pen color.

GENERAL INSTRUCTIONS FOR USING MULTIPLE DESIGNWORKS COMPONENTS IN ONE DESIGN:

- 1. Refer to the color information bar on your machine or your design instructions to determine the order in which you use traditional machine embroidery (needle and thread) or the PaintWork tool. PaintWork files are denoted by PW at the end of a file name.
- 2. Create any CrystalWork templates using the CrystalWork files and the CrystalWork tool following the CrystalWork Instructions. These files are denoted by _CR at the end of the file name. The templates can be created either before or after the design is stitched, but the crystals will be applied after the embroidery and/or paint is completed.

Design contains a loose fill.

Some solid areas shown are not stitched.

- L Design is larger than 5" (127 mm) in either direction.
- S Design is smaller than 1.5" (38.1 mm) in either direction.



Instructions

CRYSTALWORK INSTRUCTIONS:

- 1. Remove upper thread from the machine.
- Attach the Straight Stitch/CutWork Stitch Plate for your machine.
- 3. Remove the needle and replace with the correct size punch tool (SS6, SS10, SS12, SS16 as noted on the Color Bar of the machine or in the crystal chart for the design collection) with the flat side toward the back. Tighten the needle
- 4. Attach Presser Foot #48.
- 5. Place the CrystalWork container on the stitch plate with the center positioning pin in the rear hole of the stitch plate.
- 6. Attach the punch plate (same size as the punch tool used) on top of the container so that it sits flush with the top.
- 7. Lower the punch tool by turning the handwheel to check that the container lines up correctly. **See Photo 1**
- 8. Hoop parchment paper up-side down and trim all excess from edges. **See Photos 2 and 3**
- Cut a piece of rhinestone template material slightly larger than the design. Remove backing from the template material and place the sticky side down on the top of the parchment paper in the center of the hoop. See Photo 4
- Place hoop on machine and use your machine's check feature to ensure that the template material is positioned correctly. Punch the first color change.
 - Note: The machine will prompt you when the container is full and needs to be emptied. However, you may also wish to empty the container between color changes. ANY time you remove the container for cleaning, be sure to repeat Step 7 to ensure that the container is positioned properly. Check the back of the parchment paper between color changes also to remove any stray dots that may be stuck to the paper.
- 11. If more than one size crystal is used in the design, replace the punch tool and the punch plate on the top of the container with sizes to correspond with the size shown on the Color Bar of the machine. Repeat this process as needed until the design is finished. See Photo 5
- 12. Carefully peel the rhinestone template material away from the parchment paper and place on a piece of rhinestone template backboard. Smooth into place.
- 13. Pour the largest size of crystals used in the design over the template and use a small rhinestone brush to push them into place. **See Photos 6 and 7**
- 14. Make sure that all holes of that size are filled, and that all crystals are facing upright.
- 15. Repeat Steps 13 and 14 for any additional sizes, continuing with the next largest size and progressing to the smallest size.
- 16. Once all holes in the template are filled with the correct size crystals, check to ensure that all crystals are facing up and that there are no stray crystals. **See Photo 8**


Note: Design pictured is for instructional purposes and is not included in this collection.

























Instructions

- 17. Cut a piece of rhinestone application tape slightly larger than the design.
- 18. Remove the backing and place tape sticky side down over the crystal template. **See Photo 9**
- 19. Smooth application tape over the top of each crystal using your fingertips or the rhinestone brush to ensure that all crystals are adhered to the tape.
- 20. Slowly peel transfer tape away from the template. The crystals should come up adhered to the tape. See Photo 10 If individual crystals are loose or missing, lay the tape carefully back down and re-adhere crystals.
- 21. Position the transfer tape with the crystals sticky side down onto your project. **See Photo 11**
- 22. Place a press cloth over the transfer tape and press firmly with a hot iron for approximately 15 seconds. If the transfer is larger than the iron, move the iron to another area and repeat. **Note:** Time and temperature given here are meant as guidelines only. Refer to instructions from the crystal manufacturer for best results.
- 23. Allow the transfer to cool completely before peeling the transfer tape away. See Photo 12




- 1. Remove the upper thread and needle from the machine.
- 2. Attach the Straight Stitch/CutWork Stitch Plate to the machine.
- 3. Open the clamping lever on the PaintWork tool and slide the appropriate pen adaptor into the shaft of the tool. Close the clamping lever.
- 4. Attach the PaintWork tool over the presser foot holder cone and secure with the lever.
- 5. Prior to hooping, iron the fabric to remove any wrinkles. The fabric must be smooth and hooped securely in order to ensure proper working of the tool.
- 6. Hoop your project using the appropriate stabilizing method.

Method A:

- a. Hoop a piece of Stabil-Stick Cut Away or Stabil-Stick Tear Away by itself in the hoop.
- b. Score and remove the paper.
- c. Place the fabric to be painted over the sticky surface with right side up. Gently smooth into position. For best results, the stabilizer should be adhered to as much area of the fabric as possible.

Method B

- a. Spray stabilizer of your choice with a generous amount of temporary spray adhesive
- b. Place the sprayed side of the stabilizer on the wrong side of the fabric. Hoop all layers as one unit.
- 7. Attach the hoop to the machine.
- 8. Swing the pen guard down. Release the clamping lever and insert the appropriate pen with a slight twisting motion until the tip just touches the pen guard. Close the clamping lever. The pen should now be held firmly in place. NOTE: Although there should be some pressure against the pen as it is inserted, do not use excessive force without supporting the PaintWork tool.
- 9. Swing the pen guard up and start painting using the Start / Stop button on the machine. NOTE: It is advisable to hoop a test piece of fabric to test for pen pressure prior to the painting on the actual project. An alternative to this is to cut a hoop sized piece of Stabil-Stick, remove the paper from the entire back, and place the Stabil-Stick over the hooped project. Start the machine and paint for a few seconds. Adjust the pen pressure as needed to achieve the look you desire. (See Photo 1) Turning the dial counter-clockwise decreases the pressure. Turning the dial clockwise increases the pressure. When you have achieved the desired effect, remove the Stabil-Stick from the top and re-start the design from the beginning.
- 10. When the first color is finished, swing the pen guard down. Open the clamping lever and remove the pen.
- 11. Clean the pen guard between color changes and allow fabric to dry between color changes to avoid mixing colors. **Tip:** To help guarantee colors will not mix, remove the hoop from the machine, but not the fabric from the hoop. Use a small, applique iron to heat the color. Replace the hoop and continue your design.
- 12. Refer to the color information on the machine's screen and insert a second pen following steps above if needed. **Tip:** after raising the pen guard, wipe the tip of the pen with a white cloth before starting the color. **See Photo 2**
- 13. Use an Iron to heat set the painted fabric following pen manufacturer's instructions.











Printable

This printable design can be printed on printable fabric or heat transfer paper. This JPG design on the CD is ready for printing, just follow the manufacturer's instructions for printing and applying. WMF design format can be imported into BERNINA Embroidery Software 7 with CorelDRAW to design mixed media applications. Reference the CorelDRAW manual for tips on creating mixed media applications.



