

NovaCaddy Accessories Installation Instruction



Step 1: Install the Accessories Station at cart frame.



Pic1

Step 2: Attach the Scorecard Holder to the Accessories Station with screw included (Pic3).



Pic 3



Rubber Liner

Pic 2

Install the clamp style accessories station at frame by using the Allen wrench (pic1). Rubber Liner (pic2) need to be removed for S2R and P1D3.

Step 3: Attach Umbrella Holder to Accessories Station. (Pic 4).

