Cedar Barrel Sauna Assembly Instructions

Cove Installation (Optional)



Line up the cove pieces starting with the smallest pieces on the end and working towards the middle forming a semi circle.

Place 2 ½" (64mm) screws in the pre-drilled holes to assist in the assembly of the cove.



Center the 2 middle (longest) pieces under the lip of the sauna.

Ensure cove pieces are tight to the wall of the sauna.



Secure with 2 ½" (64mm) screws from the underneath.



Fasten each cove piece to the next through the pre drilled holes on the front of each piece using a 2 $\frac{1}{2}$ " (64mm) screw.

Manufactured by:



Cedar Barrel Sauna Assembly Instructions

Cove Installation (Optional)



Continue building the cove from the middle until the cove is complete.



When installed, the cove should be centered and tight together and to the wall of the sauna.

