

Please read and understand the complete instructions prior to assembly and use of your outdoor leisure product. Customer agrees not to hold Dundalk LeisureCraft Inc. and any of its authorized dealers liable for improper installation, maintenance and repair of this product



Requirements:

- * 2 People (recommended)
 - * Staple Gun
- * Cordless Drill (we supply the bit)
 - * Tape Measure
 - * Rubber Mallet
 - * Utility Knife

View the assembly process on You Tibe





Organize your pieces neatly on the ground.



Set up the front wall where the Tropical Paradise tiki bar will be placed.



Slide one of the side wall pieces flush into the front wall.



Holding the walls flush together, secure them using the provided 2 ½" (64mm) screws from the inside of the front wall into the side wall.





Repeat this process for the other side wall piece.



Place the bar top onto the assembled bottom base.

* The bar top should "slip" over the assembled walls.



If the roof option is chosen, secure the bar top to the base through the post holes.

If the roof option is not selected, continue to next step.



Secure the base to the bar top using the provided 2 $\frac{1}{2}$ " (64mm) screws from the inside of the front wall up into the bar top.

Be careful not to overtighten as screws will go through top of bar.





Place the bar cabinet inside the base of the tiki bar.

If no bar cabinet was chosen, skip the next 3 steps.



Slide the bar cabinet tight to the front wall of the tiki bar.



Secure the frame on the inside of the bar cabinet to the tiki bar base using 2 $\frac{1}{2}$ " (64mm) screws.



Repeat the process by fastening inside the mini fridge compartment to the tiki bar base using 2 ½" (64mm) screws.





Insert the bar posts into the holes on the top of the tiki bar.



The posts should go into the holes so they sit tight to the tiki bar top.



Lay the roof frame on a clean flat surface.



Organize the roof support pieces.

The longer 4 are for the corners and the shorter ones go in between.





To make installation easier, pre place 3" (76mm) screws into the ends of the roof supports.



Locate the roof cap assembly.



With assistance from a helper, hold the corner roof support flush to the corner of the roof cap assembly. Secure the post to the assembly with 3" (76mm) screws.

(2 screws per corner)



Repeat for the remaining 3 corners.





Center the roof cap assembly on top of the roof frame.



Screw the corners of the roof supports to the roof frame using 3" (76mm) screws.

Ensure that the supports are centered on the corners.



Position one of the shorter supports flush to the side and top of the side of the roof cap and secure with 3" (76mm) screws.



Install 3 supports for each side.

1 at either end and one centered between them.

Repeat for the other side.





Center 1 roof support on the end and secure as in the previous step.

Repeat for the other end.



Screw the bottoms of the roof supports to the roof frame using 3" (76mm) screws.



Gather up and organize your roof boards.

The short ones are for the ends and the longer ones are for the sides.



The roof boards are tongue and groove.

The boards with a straight cut on the groove side are for the bottom of the roof.







Starting on one of the sides, insert the shortest board up tight to the roof cap.



Secure the roof boards into the roof supports with the provided 2" (51mm) screws.



Continue adding the roof boards working around the roof assembly.

Use a rubber mallet to tap boards tight together.



Install the bottom roof boards in the same manner.





Gather up your synthetic palm thatch pieces.



Place the thatch onto the roof with the synthetic palm leaves hanging over the bottom as in picture.



Secure with staples

Please note you are going to want to use a lot of staples to hold thatch pieces to the roof.



Add the next piece of thatch overlapping the last piece by a couple inches.

(To keep the thatch level you can use the roof board as a guide for a straight line)





When you get to the end of the roof, cut off the excess thatch with a utility knife.



Use the cut off piece to start the first row on the short side. Cut the excess off the corner in the same manner.



Continue to add the synthetic thatch in this manner around the roof.



Cut some thatch into "thirds"
These will be used in the corners.





Take the cut corner pieces and fasten them to the corners with staples.

This will cover up the corners of the thatch underneath.



Fasten a row of thatch, then the cut corner pieces. Continue this method until you get to the top.



When you reach the top, overlap the 2 sides as shown.



Cut approximately 3-4" of the top of a few pieces of thatch.





Use these cut pieces to cover the thatch at the top.



Attach 2 more corner pieces at each end of the roof.



Use cut corner pieces to make a ridge cap cover coming in from each end until they meet in the middle.



Now cut some thatch pieces just past the leaf ends as in picture.







Overlap the 2 cut pieces back to back then secure into place with staples.

Secure any loos thatch you may find with staples



With a helper, place the roof up onto the bar posts.

Center the roof ensuring it is overhanging the same front and back and side to side.



Secure the bar posts to the assembled roof using the supplied lag screws.

Repeat on all 4 corners.



Secure the bar posts from the inside of the base using the provided 3" (76mm) wood screws.

Repeat on other side





Congratulations on the assembly of your Dundalk Leisurecraft Tropical Paradise Tiki Bar!

For assistance in the assembly of your Tiki Bar please visit our support page at: https://www.dundalkleisurecraft.com/support/

> Or to view the assembly process got to: https://www.youtube.com/watch?v=-vwFM6YBRAg