



- 2) Slide provided bolts through the baseplate, then slide Life jacket hook onto bolts in front of baseplate.
 - 3) Realign fork with base plate, and start bolts into holes by hand.
 - 4)Tighten with Allen Head Socket