

WAKESURF SOLUTIONS LLC

Innovative Products, Better Experiences

Thank you for your purchase from Wakesurf Solutions!

Installation Instructions

1) Using Provided Allen Wrench, Remove the 2 bolts that hold the fork to the base plate on the side of the rack. Be careful to not let the fork drop when removing the second bolt. (see picture)



2) With provided bolts and thread lock, put a drop on each one of the new bolts. A little goes a long way.

3) Insert bolts through Wakesurf Solutions Rack hook.

4) Line up the Rack Hook with the holes in the baseplate and insert.

5) Once the hook and bolts are through the side of the fork, line up with the holes in your baseplate and start threading by hand.

6) Once both bolts are started, take the provided allen wrench and tighten securely. You will not break the bolts. You want these tight, but do not use an impact wrench!

YOUR DONE!