



WAKESURF SOLUTIONS LLC

Innovative Products, Better Experiences

Thank you for your purchase from Wakesurf Solutions!

Installation Instructions

- 1) Using Provided Allen Wrench, Remove the 2 bolts that hold the fork to the base plate on the back of the rack. Be careful to not let the fork drop when removing the last bolt. (see picture)
- 2) With provided bolts and thread lock, put a drop on each one of the new bolts. A little goes a long way.
- 3) Insert bolts through Wakesurf Solutions Rack hook, in the orientation you want the hook to mount to your rack (outwards or inwards).
- 4) Line up the Rack Hook with the holes in the baseplate and insert.
- 5) Once the hook and bolts are through the back of the baseplate, take your fork and start each bolt by hand.
- 6) Once both are started, take the provided allen wrench and tighten securely. You will not break the bolts. You want these tight, but do not use an impact wrench!

YOUR DONE!