



5/29/13

**1984-2001 JEEP CHEROKEE
REAR BUMPER
P/N: 10-05184
INSTALLATION INSTRUCTIONS**

PART LIST

20-05184-1	Rear Bumper	1
20-05184-2	Frame Mount, Drvr	1
20-05184-3	Frame Mount, Pass	1
20-72033	Hardware Pack, Bumper Brackets	
13-20142-Z	7/16-14 x 1-1/4" Bolt	8
13-10133-Z	7/16-14 Nyloc Nut	8
13-30117-Z	7/16 Flat Washer	16

PLEASE NOTE

On 1997-2001 models the rear portion of the fender flare is part of the original bumper which gets removed. RCD recommends the use of aftermarket fender flares in this instance.

RCD Quarter Panel Cover Kit 10-05384 is recommended on 1997-2001 models.

Rear Bumper Installation Instructions

1. Remove rear bumper by removing four bolts on each side attaching bumper to body. On later models, with wrap around end caps, first remove the end caps by removing the recessed screw at the lower front and 6mm bolt and nut at the lower rear and sliding the end cap towards the rear.
2. Install Frame Mount Brackets to original bumper mounting location with original hardware.
3. Place bumper on vehicle and loosely attach with 7/16" hardware provided.
4. Align bumper to body and tighten bolts.

