



5/29/13

**1984-2001 JEEP CHEROKEE
REAR CORNER GUARDS
P/N: 10-05384
INSTALLATION INSTRUCTIONS**

PART LIST

20-05184-4	Rear Corner Guard, Passenger	1
20-05184-5	Rear Corner Guard, Driver	1
20-72046	Hardware Pack, Corner Guards	
13-24069-SS	1/4"-20 x 3/4" Button Head Bolt, Stainless Steel	14
13-11151-Z	1/4"-20 Rivet Nut	10
13-30993-SS	1/4" Flat Washer, Stainless Steel	14
13-10161-Z	1/4"-20 Nyloc Nut	4

Rear Corner Guard Installation Instructions

1. Working on one side at a time. Position Corner Guard on vehicle and mark all holes to be drilled.
2. Remove Corner Guard and drill 25/64" holes in body and 9/32" holes in bumper.
3. Once all holes are drilled, install Rivet Nuts (13-11151-Z) in 25/64" holes in body. A Rivet Nut Setting Tool is necessary to accomplish this.
4. Position Corner Guard in place and install all hardware. It is recommended to use Anti-Seize on the threads of the bolts.
5. Repeat process on opposite side.

