



1984-2001 JEEP CHEROKEE

3/11/13

ROOF RACK

P/N: 10-05584

INSTALLATION INSTRUCTIONS

PART LIST

ITEM	DESCRIPTION	QTY.
Box 1	10-05584	
20-05584-1	Cherokee Roof Rack	1
20-05584-2	Drip Rail Bracket	4
20-05584-3	Drip Rail Clamp	4
20-05584-4	L-Bracket	4
20-05584-5	Air Dam	1
20-72111	Hardware Pack, Mounting	
13-20536-Z	5/16"x1" Blot	16
13-10155-Z	5/16" Nyloc Nut	16
13-30187-Z	5/16" Flat Washer	32
13-22301-Z	1/4"x3/4" Bolt	4
13-10161-Z	1/4" Nyloc Nut	4
13-30195-Z	1/4" Flat Washer	8
20-72124	Hardware Pack, Air Dam	
13-24069-SS	1/4"x3/4" Button Head Bolt, Stainless Steel	8
13-11164-SS	1/4" Nyloc Nut, Stainless Steel	8
13-30993-SS	1/4" Flat Washer, Stainless Steel	16
20-72137	Hardware Pack, Weatherstrip	
15-12214	Weatherstrip	5ft.

Roof Rack Installation Instructions

1. If so equipped, remove existing roof rack crossbars by removing the side rail end caps and sliding them out. Re-install end caps.
2. Attach L-Brackets (20-05584-4) and Drip Rail Brackets (20-05584-2) to Roof Rack (20-05584-1) with 5/16" hardware provided. Tighten bolts until just snug, but can still move slightly.
3. Lift Roof Rack onto roof of vehicle and position. Once in desired position tighten all 5/16" bolts.
4. Install Drip Rail Clamps (20-05584-3) using 1/4" hardware provided.
5. Install Weatherstrip (15-12214) along lower edge of Air Dam (20-05584-5). It may be necessary to trim Weatherstrip to length.
6. Place Air Dam at front of Roof Rack and attach with 1/4" Stainless Steel Hardware provided.

NOTE: If vehicle was originally equipped with full length roof rails. Trimming of the Air Dam may be required to fit.

