



SUSPENSION SYSTEMS

2/7/02

Skidplate Mount Kit '99-'00 Chevy/GMC 2WD P/N 10-11000 (To be used with RCD lift kit P/N 10-41000)

Part List

<u>Item</u>	<u>Description</u>	<u>Qty</u>
20-11000-1	Skidplate Mount Hoop (Chevy)	1
20-11000-2	Skidplate Lower Mount	1
20-68799	Hardware Pack Containing: (Skidplate)	
13-20164-Z	Hex Bolt, 1/2"-13 x 1-1/2"	2
13-20081-Z	Hex Bolt, 3/8"-16 x 1-1/4"	4
13-30034-Z	Flat Washer, 1/2" SAE	4
13-30012-Z	Flat Washer, 3/8"	8
13-10038-Z	Nyloc Nut, 1/2"-13	2
13-10022-Z	Nyloc Nut, 3/8"-16	4

The following parts are to be used in conjunction with this kit. Due to packaging they must be ordered separately.

10-10300	Universal Skidplate Kit	
20-10300-1	Skidplate, (Stainless Steel #8 Mirror Finish)	1
20-68565	Hardware Pack Containing: (Skidplate)	
13-22821	Flat Head Socket, 3/8"-16 x 1" Lg.	2
13-30012-Z	Flat Washer, 3/8"	2
13-10022-Z	Nyloc Nut, 3/8"-16	2

OR

10-10600	Universal Skidplate Kit	
20-10600-1	Skidplate, (Aluminum #4 Satin Finish)	1
20-68552	Hardware Pack Containing: (Skidplate)	
13-20192-Z	Flat Head Socket, 3/8"-16 x 1" Lg.	2
13-30012-Z	Flat Washer, 3/8" SAE	2
13-10022-Z	Nyloc Nut, 3/8"-16	2

NOTE: This item is designed as a decorative accessory item. It is not intended for use as additional vehicle protection.

INSTALLATION

- 1) If equipped, remove lower tow hook mounting bolt (one on each frame rail).
- 2) Align mounting holes in Skidplate Mount Hoop (20-11000-1) to tow hook mounting holes in frame (**Illustration 1**). Attach Hoop, and tow hooks if applicable, to frame with 1/2"-13 x 1-1/2" Hex Bolts, Washers and Nyloc Nuts.
- 3) Install Skidplate Lower Mount (20-11000-2) to RCD Front Crossmember. Position Mount to Crossmember with widest part of bracket on bottom and facing front of vehicle. Attach vertical section of mount to face of Crossmember using two 3/8"-16 x 1-1/4" Hex Bolts, Washers and Nyloc Nuts provided. Torque nuts to 30 ft. lbs.

4) Attach bottom of factory Skidplate to top two mounting holes of the Skidplate Lower Mount using existing hardware.

5) Locate the four Skidplate bolt hole mounting locations (two tabs on Mount Hoop and the bottom two holes in Skidplate Lower Mount). Align the four holes and attach Skidplate with 3/8"-16 x 1-1/4" Hex Bolts, Washers and Nyloc Nuts provided.

