



SUSPENSION SYSTEMS

2/7/02

Skidplate Mount Kit *'88- '98 Chevy/GMC 4WD* **P/N 10-11089**

(To be used with RCD lift kit P/N 10-41089)

Part List

<u>Item</u>	<u>Description</u>	<u>Qty</u>
20-11089-1	Skidplate Mount Hoop (Chevy)	1
20-11089-2	Skidplate Lower Mount	1
20-69163	Hardware Pack Containing: (Skidplate)	
13-20053-Z	Hex Bolt, 3/8"-16 x 1"	8
13-30012-Z	Flat Washer, 3/8"	16
13-10022-Z	Nyloc Nut, 3/8"-16	8

****The following parts are to be used in conjunction with this kit. Due to packaging they must be ordered separately.****

10-10300	Universal Skidplate Kit	
20-10300-1	Skidplate, (Stainless Steel #8 Mirror Finish)	1
20-68565	Hardware Pack Containing: (Skidplate)	
13-22821	Flat Head Socket, 3/8"-16 x 1" Lg.	2
13-30012-Z	Flat Washer, 3/8"	2
13-10022-Z	Nyloc Nut, 3/8"-16	2

OR

10-10600	Universal Skidplate Kit	
20-10600-1	Skidplate, (Aluminum #4 Satin Finish)	1
20-68552	Hardware Pack Containing: (Skidplate)	
13-20192-Z	Flat Head Socket, 3/8"-16 x 1" Lg.	2
13-30012-Z	Flat Washer, 3/8" SAE	2
13-10022-Z	Nyloc Nut, 3/8"-16	2

NOTE: This item is designed as a decorative accessory item. It is not intended for use as additional vehicle protection.

INSTALLATION

1) Position Skidplate Lower Mount (20-11089-2) to RCD Front Crossmember with rectangle side of bracket on bottom and facing front of vehicle (**Illustration**). Align the Mount radius edges with lightening holes in face of crossmember. Mark the two (2) mounting hole locations. Remove Mount and drill 3/8" holes. Install Mount to face of crossmember using two 3/8"-16 x 1" Hex Bolts, Washers and Nyloc Nuts provided. Torque nuts to 30 ft. lbs.

2) Loosely install bottom of Skidplate (20-10300-1, or 20-10600-1) to Lower Mount using 3/8"-16 x 1" Hex Bolts, Washers and Nyloc Nuts provided.

3) Loosely attach top of Skidplate to tabs on bottom of Mount Hoop (20-11089-1) using 3/8" hardware provided. Raise and support top of assembly against face of front bumper. Center Hoop to bumper and mark the four (4) mounting holes on Hoop ends. Remove hoop and drill 3/8" holes.

4) Install Hoop to bumper with 3/8"-16 x 1" Hex Bolts, Washers and Nyloc Nut.

5) Install Skidplate to Hoop with 3/8" hardware provided.

6) Torque all 3/8" nuts to 30 ft. lbs.

