



SUSPENSION SYSTEMS

4/3/01

Skidplate Mount Kit
'99-'00 Chevy/GMC 4WD
P/N 10-11099
(To be used with RCD lift kit P/N 10-41099)

Part List

<u>Item</u>	<u>Description</u>	<u>Qty</u>
20-11099-1	Skidplate Mount Hoop (Chevy)	1
20-68474	Hardware Pack Containing: (Skidplate Mount Hoop)	
13-20164-Z	Hex Bolt, 1/2"-13 x 1-1/2"	2
13-20081-Z	Hex Bolt, 3/8"-16 x 1-1/4"	2
13-30034-Z	Flat Washer, 1/2"	4
13-30012-Z	Flat Washer, 3/8"	2
13-10038-Z	Nyloc Nut, 12"-13	2

The following parts are to be used in conjunction with this kit. They are packaged and must be ordered separately.

10-10300	Universal Skidplate Kit	
20-10300-1	Skidplate, Stainless Steel	1
20-68565	Hardware Pack Containing: (Skidplate)	
13-22821	Flat Head Socket, 3/8"-16 x 1" Lg.	2
13-30012-Z	Flat Washer, 3/8"	2
13-10022-Z	Nyloc Nut, 3/8"-16	2

OR

10-10600	Universal Skidplate Kit	
20-10600-1	Skidplate, Aluminum	1
20-68552	Hardware Pack Containing: (Skidplate)	
13-20192-Z	Flat Head Socket, 3/8"-16 x 1" Lg.	2
13-30012-Z	Flat Washer, 3/8" SAE	2
13-10022-Z	Nyloc Nut, 3/8"-16	2

NOTE: This item is designed as a decorative accessory item. It is not intended for use as additional vehicle protection. To be used with RCD lift kit.

INSTALLATION:

NOTE: It may be necessary to trim lower valance to clearance Mount Hoop.

1) Remove tow hooks (one on both frame rails).

2) Refer to **Illustration 1** and align mounting holes in Skidplate Mount Hoop (20-11099-1) to tow hook mounting holes in frame. Attach hoop and tow hooks to frame with 1/2"-13 x 1-1/2" Hex Bolts and Nyloc Nuts.

3) Locate the four Skidplate bolt hole mounting locations (two tabs on Mount Hoop and two holes in Front Crossmember). Align the four holes and attach Skidplate with 3/8"-16 x 1" Flat Head Screws, Washers and Nyloc Nuts provided. Use 3/8"-16 x 1-1/4" Hex Bolts attach bottom of plate.

Illustration 1

