



SUSPENSION SYSTEMS

4/2/01

Skidplate Mount Kit *'99-'00 Chevy/GMC 4WD 8 Lug* P/N 10-11899

(To be used with RCD lift kit P/N 10-41800 & 41899)

Part List

<u>Item</u>	<u>Description</u>	<u>Qty</u>
20-11899-1	Skidplate Mount Hoop (Chevy)	1
20-68487	Hardware Pack Containing: (Skidplate Mount Hoop)	
13-22964-Z	Hex Bolt, 12mm-1.75 x 40mm	4
13-30460-Z	Lock Washer, 12mm	4
13-10358-Z	Nyloc Nut, 12mm-1.75	4

The following parts are to be used in conjunction with this kit. They are packaged and must be ordered separately.

10-10300	Universal Stainless Steel Skidplate Kit	
20-10300-1	Skidplate, Stainless	1
20-68565	Hardware Pack Containing: (Skidplate)	
13-22821	Flat Head Socket, 3/8"-16 x 1" Lg.	2
13-30012-Z	Flat Washer, 3/8"	2
13-10022-Z	Nyloc Nut, 3/8"-16	2

OR

10-10600	Universal Aluminum Skidplate Kit	
20-10600-1	Skidplate, Aluminum	1
20-68552	Hardware Pack Containing: (Skidplate)	
13-20192-Z	Flat Head Socket, 3/8"-16 x 1" Lg.	2
13-30012-Z	Flat Washer, 3/8" SAE	2
13-10022-Z	Nyloc Nut, 3/8"-16	2

NOTE: This item is designed as a decorative accessory item. It is not intended for use as additional vehicle protection. Also it is designed to be used with RCD Lift Kits.

INSTALLATION:

NOTE: You may need to trim lower valance to clearance the Mount Hoop.

1) Remove tow hooks (one on each frame rail).

2) Align mounting holes in Skidplate Mount Hoop (20-11899-1) to tow hook mounting holes in frame (**Illustration 1**). Attach hoop and tow hooks to frame with 12mm-1.75 x 40mm Hex Bolts and Nyloc Nuts.

3) Locate the four Skidplate bolt hole mounting locations (two tabs on Mount Hoop and two holes in Front Crossmember). Align the four holes and attach top of Skidplate to Mount Hoop with 3/8"-16 x 1" Flat Head Screws, Washers and Nyloc Nuts provided. Use existing Hex Bolts on bottom.

Illustration 1

