



1984-2001 JEEP CHEROKEE

06/05/13

ROCK SLIDERS

P/N: 10-15084

INSTALLATION INSTRUCTIONS

### PART LIST

<b>ITEM</b>	<b>DESCRIPTION</b>	<b>QTY.</b>
<b>Box 1</b>	<b>10-15084</b>	
20-15084-1	Cherokee Rock Slider, Drivers Side	1
20-15084-2	Cherokee Rock Slider, Passengers Side	1
20-72098	Hardware Pack, Mounting	
20-15084-6	Spacer, Front	2
13-24095-Z	3/8" x 1" Thread Forming Screw	14
13-20053-Z	3/8"-16 x 1" Bolt	2
13-10022-Z	3/8"-16 Nyloc Nut	2
13-21352-Z	1/4"-20 x 1" Bolt	16
13-24069-SS	1/4"-20 x 3/4" Button Head Bolt	18
13-24082-Z	1/4" x 1-1/4" Self Drilling Bolt	4
13-11151-Z	1/4"-20 Rivet Nut	18
13-10161-Z	1/4"-20 Nyloc Nut	16
13-30012-Z	3/8" Flat Washer	4
13-30993-SS	1/4" Flat Washer Stainless Steel	18
13-31006-Z	1/4" Flat Washer	32

## **Rock Slider Installation Instructions**

1. Working on one side at a time, using floor jack, raise Rock Slider so it is against Rocker Panel and Frame of vehicle. NOTE: If installing with RCD Long Arm Kit, Slider will line up with holes in frame bracket. If installing alone, Spacer (20-15084-6) will fit between Slider and Frame at front. (See Illustration)
2. Using a scribe, mark all holes on Rocker Panel, Pinch Weld and Frame.
3. Lower Rock Slider, then center punch centers of all hole locations marked.
4. Drill 25/64" holes in the Rocker Panel, 9/32" holes in the Pinch Weld, and 21/64" holes where the 3/8" Thread Forming Bolts will be installed. Drill the hole into rear spring pocket, for the 3/8"-16 x 1" bolt, to 13/32". Holes for the two Self Drilling Bolts will not need to be drilled.
5. Once all holes are drilled, install Rivet Nuts (13-11151-Z) in 25/64" holes in Rocker Panel. A Rivet Nut Setting Tool is necessary to accomplish this.
6. Raise Rock Slider in place and install all hardware. Be sure to use Anti-Seize on the Stainless Steel bolts.
7. Repeat process on opposite side.

