



To use the center mounting configuration, place the supplied 6mm hex head bolt in the counter sunk hex shaped hole. Use supplied locking nuts and washers to mount your accessories.

To use the offset mounting configuration. Screw the supplied 6mm studs into the floating mounting nuts. Make sure stud is screwed all the way in. Use supplied locking nuts and washers to mount your accessories.

