



## Installation Instructions for Radiator Guard for 1997-2006 Jeep® TJ Wrangler

Thank you for purchasing your new Skid Row Offroad radiator guard. It is designed to give you peace of mind while traversing even the toughest trails.

Your skid plate package should come complete with the following parts:

1. (1) Radiator Guard
2. (1) 3/8-16 UNC x .75" Self Tapping Bolt

**Step 1:** Remove the lower portion of the body mount directly under the grill.

**Step 2:** Place the radiator guard in position within the chassis portion of the body mount and then re-install the lower portion of the body mount sandwiching the radiator guard in place.

**Step 3:** Align the radiator guard with the lower tank of the radiator. Mark and then drill a 5/16" hole into the passenger side of the frame using the hole in the guard as a guide.

**Note:** The tab on the guard will not sit flat on the chassis until after the bolt is tightened.

**Note:** You may find it easier if you first mark the hole location and then remove the guard to drill the hole.

**Step 4:** Install the 3/8-16x.75" self-tapping bolt into the hole just drilled and tighten.

**Step 5:** Tighten the body mounting bolt once everything is fit together and you're done.



We hope you enjoy your new Skid Row Offroad radiator guard!

Sincerely,

*Your friends at Skid Row Offroad*

**Skid Row Offroad**  
100 Creek Road, Carlisle, PA 17013  
Phone 717-701-8315

[www.SkidRowOffroad.com](http://www.SkidRowOffroad.com)



**Skid Row Offroad**