

Installation Instructions
for
Foot Pegs for Jeep® JK and JL, Front Doors

Thank you for purchasing your new Skid Row Offroad Foot Pegs.
Your Foot Peg package should come complete with the following parts:

1. (1) “Hers” Driver’s Side Foot Peg
2. (1) “His” Passenger Side Foot Peg
3. (2) Hairpin Cotter Pins
4. (2) Vinyl Caps



Step 1: Slip the vinyl caps onto the tab on each of the foot pegs.

Step 2: After removing your Jeep’s doors, place each foot peg into the lower hinge on each side, put one of the hairpin cotter pins through the hole below the hinge, and you’re ready to enjoy driving doorless with a comfortable place to put your foot!

We hope you enjoy your new Foot Pegs!

Sincerely,

Your friends at Skid Row Offroad

Skid Row Offroad
100 Creek Road, Carlisle, PA 17013
Phone 717-701-8315

www.SkidRowOffroad.com



Skid Row Offroad