



## Transfer Case Skid Plate Installation Instructions for 1995-2004 Toyota Tacoma

Thank you for purchasing your new Skid Row Offroad transfer case skid plate. It is designed to give you peace of mind while traversing even the toughest trails.

Your skid plate package should come complete with the following parts:

1. (1) Transfer Case Skid Plate
2. (4) 3/8-16 UNC x .75" Self-Tapping Hex Head Bolts
3. (2) 3/8-16 UNC x 3.0" Carriage Head Bolt
4. (2) 3/8-16 UNC Hex Nut
5. (2) 3/8" Lock Washers
6. (6) 3/8 Flat Washers

**Step 1:** Remove the factory "skid plate" from the transfer case.

**Step 2:** Lift the new transfer case skid plate into place as shown to the right. There should be existing holes in the chassis cross-member. You may want to use a floor jack to hold the skid plate in position.

**Step 3:** Install two 3/8-16 UNC x 3.0" carriage head bolts, flat washers, lock washers, and nuts. Center the skid plate on the chassis and tighten the bolts.

**Step 4:** Drill four 5/16" holes into the chassis using the holes in the skid plate as a guide.

**Step 5:** Install the four 3/8-16 UNC x .75" self-tapping hex head bolts with flat washers.

**Step 6:** You're ready to hit the trail!



We hope you enjoy your new Skid Row Offroad transfer case skid plate!

Sincerely,

*Your friends at Skid Row Offroad*

**Skid Row Offroad**  
100 Creek Road, Carlisle, PA 17013  
Phone 717-701-8315

[www.SkidRowOffroad.com](http://www.SkidRowOffroad.com)



**Skid Row Offroad**