



Installation Instructions
for
Front Skid Plate, TA-0002
for
1995-2004 Toyota Tacoma or
1996-2002 Toyota 4Runner

Thank you for purchasing your new Skid Row Offroad front skid plate. It is designed to give you peace of mind while traversing even the toughest trails.

Your skid plate package should come complete with the following parts:

1. (1) Front Skid Plate
2. No additional hardware is provided. Re-use the original hardware from the factory skid plate.

Step 1: Remove the factory “skid plate” from the front of the vehicle. Retain the original hardware as it will be re-used. If you are missing the original bolts, they are M8-1.25x 20mm hex head bolts with flat washers.

Step 2: Lift the new front skid plate into place as shown to the right and bolt in place using the original hardware.

Step 3: Tighten all seven bolts and you’re ready to hit the trail!

We hope you enjoy your new Skid Row Offroad front skid plate!

Sincerely,
Your friends at Skid Row Offroad



Skid Row Offroad
100 Creek Road, Carlisle, PA 17013
Phone 717-701-8315

www.SkidRowOffroad.com



Skid Row Offroad