

Transfer Case Skid Plate Installation Instructions for 1996-2002 Toyota 4Runner

Thank you for purchasing your new Skid Row Offroad transfer case skid plate. It is designed to give you peace of mind while traversing even the toughest trails. Your skid plate package should come complete with the following parts:

1. (1) Transfer Case Skid Plate
2. (5) 3/8-16 UNC x 3.0" Carriage Head Bolts
3. (5) 3/8-16 UNC Hex Nuts
4. (5) 3/8" Lock Washers
5. (5) 3/8 Flat Washers



Step 1: Remove the factory "skid plate" from the transfer case.

Step 2: Lift the new transfer case skid plate into place as shown above. There should be existing holes in both chassis cross-members. You may want to use a floor jack to hold the skid plate in position.

Step 3: Install two 3/8-16 UNC x 3.0" carriage head bolts, flat washers, lock washers, and nuts through the front crossmember. Leave them loose for now to help line up the holes at the rear of the skid plate.

Step 4: Install three 3/8-16 UNC x x 3.0" carriage head bolts, flat washers, lock washers, and nuts through the rear crossmember.

Step 5: Tighten all the bolts and you're ready to hit the trail!

We hope you enjoy your new Skid Row Offroad transfer case skid plate!

Sincerely,

Your friends at Skid Row Offroad

Skid Row Offroad
100 Creek Road, Carlisle, PA 17013
Phone 717-701-8315

www.SkidRowOffroad.com



Skid Row Offroad