



Installation Instructions  
For  
Front Skid Plate, TA-1005  
For  
1999-2006 Toyota Tundra & Sequoia

Thank you for purchasing your new Skid Row Offroad front skid plate. It is designed to give you peace of mind while traversing even the toughest trails.

Your skid plate package should come complete with the following parts:

1. (1) Front Skid Plate
2. (2) M8-1.25x35mm Hex Head Bolt
3. (2) ½” Aluminum Spacers
4. (2) 3/8” Flat Washers

**Step 1:** Remove the factory front skid plate and plastic “mud guards”, if equipped. You will re-use the three bolts at the front of the factory skid plate.

**Step 2:** Lift the new front skid plate into place and install the three bolts at the front of the skid plate.

**Step 3:** As shown at right, insert two ½” spacers (one per side) between the rear edge of the skid plate and the chassis cross-member and then install the two M8-1.25x35mm bolts that are included. Be sure to use the flat washers with these two bolts.

**NOTE:** Depending upon the condition of your truck these two holes may need to be tapped to clean out the factory threads. The tap size is M8-1.25.

**Step 4:** Tighten all five bolts and you’re ready to hit the trail!

We hope you enjoy your new Skid Row Offroad front skid plate!

Sincerely,

Sincerely,

*Your friends at Skid Row Offroad*



<p><b>Skid Row Offroad</b> 100 Creek Road, Carlisle, PA 17013 Phone 717-701-8315</p> <p><a href="http://www.SkidRowOffroad.com">www.SkidRowOffroad.com</a></p>	<p><b>Skid Row Offroad</b></p>
--	--------------------------------