



Installation Instructions

For

Catalytic Converter Guards, TA-1007

For

1999-2006 Toyota Tundra & 2000-2004 Toyota Sequoia

Thank you for purchasing your new Skid Row Offroad catalytic converter guards. They were designed to give you peace of mind while parked in even the toughest, middle-class neighborhoods.



Your package should come complete with the following parts:

- | | |
|---|------------------------------|
| 1. (1) Catalytic Converter Guard, Left | 4. (6) 5/16-18 Hex Nuts |
| 2. (1) Catalytic Converter Guard, Right | 5. (6) 1/4" USS Flat Washers |
| 3. (6) 5/16-18x1.0 Carriage Head Bolts | 6. (6) 5/16" Lock Washers |

Step 1: Remove the Skid Row transmission skid plate if you've already got one installed.

Step 2: Using the supplied hardware, attach the Cat Guards to the sides of the Skid Row Offroad transmission skid plate, part number TA-1002. The Cat Guards should be attached to the outside of the skid plate with the carriage head bolt threads facing inward. The idea is to keep the nuts inaccessible from

below once the skid plate is installed. Also note the position of the guards in the photo below. The wide end of the cat guard faces the narrow portion of the transmission skid plate.





Step 3: Install or re-install your Skid Row transmission skid plate as per the TA-1002 Installation Instructions.



Step 4: Tighten all four bolts and you're ready to park with your cats intact!

We hope you enjoy your new Skid Row Offroad catalytic converter guards keep your converters safe from theft!

Sincerely,
Sincerely,
Your friends at Skid Row Offroad

<p>Skid Row Offroad 100 Creek Road, Carlisle, PA 17013 Phone 717-701-8315</p> <p>www.SkidRowOffroad.com</p>	<p>   </p> <p>Skid Row Offroad</p>
--	--