

# HEAT ACTIVATED LOUVER OPENER INSTALL

## STEP ONE



**SET SCREW #1**  
(HIGHLIGHTED IN YELLOW)



## STEP ONE



**SET SCREW #2**  
(HIGHLIGHTED IN YELLOW)

**STEP ONE:** ATTACH SET SCREWS TO ATTACH CYLINDER & MOUNTING BRACKET.

**STEP TWO:** ATTACH LINKAGE BAR TO SHUTTER VANE W/ BOLT, NUT, 1/4" WASHER, & SPACER PROVIDED.

**STEP THREE:** ATTACH LINKAGE BAR TO MOUNTING BRACKET WITH PROVIDED PIN.

**STEP FOUR:** ATTACH MOUNTING BRACKET TO SHUTTER W/ 2 #12 x 1" TEK SCREWS.

\*\*\*ON 39" & 45" SHUTTERS, THE LOUVER OPENER WILL BE FLUSH WITH THE BOTTOM OF YOUR SHUTTER.

ON THE 24" SHUTTER, THE LOUVER OPENER WILL NOT BE FLUSH WITH THE BOTTOM OF THE SHUTTER.

THERE WILL BE A SMALL GAP AS SHOWN IN THE 1ST PICTURE.\*\*\*

## STEP TWO



#4 x 1" METRIC BOLT W/  
WASHER, 1/4" WASHER  
NUT, & LOCK NUT.



## STEP THREE



**PIN FOR LINKAGE BAR  
CONNECTION**  
(MAKE SURE PIN IS ATTACHED IN  
THE TOP HOLE.)