

Fabric & Supplies

2, 8 x 8 - inch contrasting fabric squares 1, 8 x 8 - inch batting square 16, 1 - inch D-rings (Dritz #117-1-65) 505 temporary fabric adhesive spray

Assembly

- Spray the wrong sides of both 8 inch fabric squares with 505 spray.
- Layer the 8 inch square of batting between the two 8 - inch squares of fabric (sticky sides toward batting).
- Press firmly together with your hands.
 Align edges and smooth out any wrinkles.

- Cut the fabric/batting sandwich into 8, 1 x 8 - inch strips.
- Topstitch ½ inch in from the edge along the length of each strip.



Make 8

Finishing

- Slip 2 D rings onto the end of each strip.
- Fold the end in ¾ inch and sew across the raw edge and backstitch.



- Flip the strip over.
- Turn the opposite end in ¼ inch and sew across the raw edge and backstitch.



