

Aluminium Pegboard Assembly

Coloured Aluminium Composite Pegboard is shipped in flat panels to ensure it arrives in good order.

Please follow the procedure below to form flat sheets into panels:

- 1. Note: Do not repeatedly fold the edges back and forth, as this will weaken the aluminium sheet and lead to failure of the corner edge.
- 2. Place the panel face down on a clean and non-abrasive surface. The face of the panel has only pegboard holes showing. Leave the plastic protective covering on this surface until the pegboard is formed into shape.



- 3. Remove the plastic protective coating from the rear of the panel. The rear of the panel has angled grooves cut into the surface. Ensure this side is facing upwards. Each panel has a 20mm side strip which is folded to an angle of 90 degrees to create a return which holds the pegboard out from the mounting surface.
- 4. Fold one of the sides upwards to 90 degrees and repeat for the adjacent side.



5. Fold these back to 45 degrees and fold the two remaining sides to 90 degrees.



6. Return the other sides to 90 degrees.



- 7. Remove the plastic protective coating from the pegboard face.
- 8. Use appropriate fixings to secure the pegboard to the wall utilising corner pegboard holes.

