

CAUTION:

The melting of wax is hot and its melting and pouring requires adult supervision.



**MAKE YOUR OWN
SOY CANDLE**

www.teepee.london

INGREDIENTS:

Bubble Candle Mould, Soy Wax, Fragrance Oil, Wick, Wick Centering Tool, Toothpick, Safety Label.

TOOLS:

Glass Jug or Glass Bowl, Pot and Stirrer.

METHOD:

- 1. Preparation:** Clean your surface and ensure you have ample space.
- 2. Getting the mould ready:** With the included toothpick, create a small hole in the middle of the candle mould.

Thread the candle wick first through the wick centering tool and then through the hole in the mould.
- 3. Set the mould aside:** Place the bubble mould onto a paper towel and set aside.
- 4. Melting the wax:** Fill a sauce pan halfway with water and bring to a low boil on medium heat.

Fill your pouring pot with the supplied wax and place the pot in the water in the saucepan to melt, stir regularly.
- 5. Adding fragrance:** Once the wax is completely melted, wait for it to cool down a little and stir in the fragrance oil.
- 6. Pouring:** Carefully pour the wax into the mould.
- 7. Unmould:** Once the candle is set, remove the wick centering tool and unmould the candle. Trim the wick as needed.