

C6 InfiRai LED Tail Lights Guide

Functionality:

Top "US/EU" Switch-This will be in off position for US-spec cars or on position for EU-spec cars.

Middle "Seq/Non Seq" Switch - When on, the turn signal will be sequential; when off, the turn signal will be standard.

Bottom "Red/Amber" Switch - When off, the turn signal will be red; when on, the turn signal will be amber.

Amber wire- this is used to give EU cars their turn signal (not connected for US-spec cars)

White wire - this can be attached to the non-ground reverse light wire with included hardware to activate the reverse light.

Installation:

1. Locate a **T15 Torx driver** and remove one screw per current tail light housing (careful not to drop the screw nor retaining clip that it secures into).
2. With the screw removed, remove each assembly and unplug the factory socket from the factory connector (the socket is bypassed with the InfiRai tails).
3. Plug the 3-wire InfiRai connector into the factory socket.
4. Re-install the InfiRai taillights and secure with the **T15** screw from **step 1** (units with LH on the back go on the driver side and units with RH on the back go on the passenger side).