



TENWAYS

CGO800S

# Front Carrier

Installation Instructions

Energized urban ride.

# Tools needed

---

No.3 Hex Key

No.4 Hex Key

No.5 Hex Key

No.8 Wrench

No.10 Wrench

Phillips Head Screwdriver



No.8 Wrench



No.10 Wrench

## Step 1

---

### Install the supports on both sides of the basket:

Use a No. 3 Hex Key and a No. 8 Wrench to pre-install the basket supports to the mounting plates on the left and right sides of the bottom of the basket.



**Note:** Don't tighten the screws fully until the entire front carrier is installed in place and the installation angle is properly adjusted in Step 7.

## Step 2

---

### Remove the headlight:

Unplug the connector of the headlight wire, and remove the headlight with a No. 5 Hex Key and a No. 10 Wrench.



## Step 3

---

### Install the headlight on the basket:

Remove the headlight support and reflector with a Phillips Head Screwdriver and a No. 8 Wrench. Fix the headlight to the front of the basket, and lock it after the angle is properly adjusted.



## Step 4

---

### Install the basket on the front fork:

Use a No. 5 Hex Key and a No. 10 Wrench to install the support chip on the front fork (using the hole where the headlight was originally installed).



**Note:** Don't tighten the screws fully until the entire front carrier is installed in place in Step 7.

## Step 5

---

Use a No. 4 Hex Key to remove the mudguard support from the front fork.



## Step 6

---

Replace the original mudguard support and front fork fixing screws with the screws supplied with the front carrier. Fix the front carrier support and the clamping block with a Phillips Head Screwdriver as shown in the figure, then tighten the screws on the mudguard support with a No. 4 Hex Key.





## Step 7

---

Connect the headlight and fix the wire using the wire clips supplied with the front carrier. Adjust the angle of the front carrier, then tighten the screws that were previously pre-tightened in Steps 1 and 4.



