

MudSling™ R/RS

Installation Guide

Fits: 2015~2023 R 1200/1250 R/RS

Parts:

- 1 - MudSling™ R12R/RS_LC
- 4 - Zip Ties
- 1 - Coupling Hex Nut
- 1 - M6 Cap Screw
- 2 - Washers

Tools Required:


- Pliers
- Side cutter
- 5mm Allen Wrench
- 10mm Open-End Wrench
- Loctite 248 (blue)

*** BEFORE BEGINNING WORK, READ THESE INSTRUCTIONS FROM START TO FINISH.**

*** PLACE BIKE ON CENTER STAND ON LEVEL GROUND.**

*** MUDSLING CAN BE INSTALLED WITHOUT REMOVING THE REAR WHEEL.**

*** NOTE: SOME PHOTOS ARE SHOWN WITH REAR TIRE REMOVED FOR CLARITY.**



1 Arrow indicates threaded stud for installation of Coupling Hex Nut.



2 Apply a small amount of Loctite 248 to threaded stud. Install Coupling Hex Nut. Secure with a 10mm Open-End Wrench. DO NOT OVERTIGHTEN



3 Hold the MudSling next to the bike in the direction of installation.



- Coupling Hex Nut
- Flat Washer
- Lock Washer
- M6 Cap Screw

Care Instructions:

Clean with soap and water. Use Armor-All to restore appearance.



4 Place MudSling above rear tire and under the existing fender. Locate the MudSling wings against the registration point (welded feature on frame).



5 Apply a small amount of Loctite 248 to the M6 Screw. Hold the MudSling in position and thread screw into the Coupling Nut finger-tight.



6 Install zip ties upward from the bottom through the slots, and around the frame.

WARNING AND DISCLAIMER: All parts manufactured, designed or sold by Machineart Moto ("MaMo") should be installed by a qualified motorcycle technician. The risk of injury is increased by improper installation or misuse of equipment. MaMo's customers must exercise good judgment in the use, control, alteration, part selection and installation, and maintenance of their motorcycles. In the event of a possible defect in material or design, or any other defect in a part manufactured, designed or sold by MaMo, the responsibility of MaMo is limited to a refund of the purchase price or the replacement of the part if MaMo determines the part to be defective, and subject to MaMo's inspection of the part within thirty (30) days from the date of purchase. (Note: any attempted repairs or modifications made to MaMo products will void this limited warranty). MaMo, under no circumstances will be responsible for incidental and/or consequential damages, property damage, personal injury damage, or damage, injury, cost or expense of any kind or nature whatsoever except as provided by law. MaMo makes no other warranty, express or implied, including without limitation any warranties of merchantability and fitness for a particular purpose.



7 After pulling the zip ties as tightly as possible by hand, use pliers to tighten zip ties fully.



8 Cut off excess zip tie length with a side cutter for best appearance.



9 Using 5mm Allen Wrench, tighten the M6 Screw. You can adjust clearance between tire and swingarm with the screw, if needed. DO NOT OVERTIGHTEN.