


**RED1RC**  
ICHARGER COMPACT STAND



B. CLEAN BACK SURFACE OF THE ICHARGER  
WHERE COMPACT STAND WILL BE INSTALLED



C1. LINE-UP TOP EDGE OF THE STAND WITH  
THE RAISED LEDGE OF THE CHARGER



SIDE VIEW

C2. LINE-UP CENTER OF THE STAND WITH  
THE CENTER OF THE CHARGER, THEN  
PRESS THE STAND TO STICK....



D. INSERT LEGS INTO THE BASE STAND



- E1. ORIENT THE POWER SUPPLY WHERE YOU WANTED THE POWER CORD TO LEAD OUT.
- E2. PLACE THE CHARGER ON TOP OF THE PWR SUPPLY AND APPROXIMATELY CENTER IT WITH THE PWR SUPPLY CHASSIS (REFERENCE FOR THE NEXT STEP)



- F. SET THE RUBBER FEET AT 75MM FROM TOP EDGE OF THE PWR SUPPLY AND LINE IT UP WITH THE FRONT LEG OF THE CHARGER (DO THE SAME AT THE OTHER SIDE)



**DONE...**

