



3102 W. Alton Avenue Santa Ana, CA 92704
1.800.436.3627 www.dekra-lite.com



INSTRUCTIONS



Diagram A

VALPARAISO POLE MOUNT

SPECIFICATIONS:

- 120 volt, 24v transformer, 53 watt per unit
- 6' lead cord, black wire
- Secured with three (3) 32' stainless steel, worm drive, adjustable bands

1. Plug decor in before installing to ensure lighting is working.
2. Hold your decor at the desired location and mark where the top and bottom of the decor piece sit on the pole.
3. Measure to ensure you have 14.5-15' clearance from the ground to the bottom of your pole decor.

4. Line up decor where it will be installed.
5. Place the first (top) band around the pole and decor. Secure the worm drive accordingly.
6. Repeat for the middle and bottom bands.