

3102 W. Alton Avenue Santa Ana, CA 92704 1.800.436.3627 www.dekra-lite.com

## **INSTRUCTIONS**





Diagram A

## TWIN TREES POLE MOUNT

## **SPECIFICATIONS:**

- 120 volt, 24v transformer, 53 watt per uni
- 6' lead cord, black wire
- Secured with three (3) 32' stainless steel worm drive, adjustable bands
- Plug decor in before installing to ensure lighting is working.
- 2. Hold your decor at the desired location and mark where the top and bottom of the decor piece sit on the pole.
- 3. Measure to ensure you have 14.5-15' clearance from the ground to the bottom of your pole decor.

- 4. Line up decor where it will be installed.
- Place the first (top) band around the pole and decor. Secure the worm drive accordingly.
- 6. Repeat for the middle and bottom bands.