



INSTALLATION INSTRUCTIONS | LUNA ENTRY PULL

1. Prepare handle height position both vertically and horizontally using a spirit level.
2. Mark the 3 centre-to-centre (CTC) screw holes exactly 95mm apart
 - a. ensure all CTC holes are the exact same distance from the edge of the door (to ensure the handle is perfectly vertical).
 - b. to ensure your CTC measurement is exactly 95mm, measure from the outside edge of one hole to the inside edge of the other.
3. Repeat step 2 on the other side of the door - in exactly the same positions.
4. Drill a 5mm hole on the first side of the door, only drilling halfway through.
5. Then repeat the drilling of holes on the other side of the door - this will ensure your holes are level and aligned.
6. Insert the three gold inset washers into screw holes on side of handle without the grub screw fixtures.
7. Hold external handle (the side without the grub screw fixtures) firmly against the door and screw all three holes with central shoulder screws.
8. Note* A standard 35mm thick door will use the 55mm length screws, the longer option screws have been included for thicker doors.
9. Take the other side of the door handle (the side the grub screws are mounted in). Insert remaining three gold inset washers and slide it over all three shoulder screw heads on the other side of the door.
10. Insert the three grub screws into place (on back plate of handle) and tighten with the hex key.

**** For glass doors we recommend using a rubber insert washer and fixing the insert washers and shoulder screws first.**